



# Load Labels in 10 Steps


1. Turn on the scanner
2. Press the latch buttons and open the supply cover.





3. Peel and discard the first four labels from the backing paper.
4. Place the label roll in the supply holder so the labels feed from the bottom.



5. Feed the blank backing paper **OVER** the peel bar.



6. Feed the paper **THROUGH** the slot at the base of the label deflector.



7. Leave 1/2 inch of first label exposed.
8. Close the supply cover.
9. Hold the backing paper and push up the label deflector until it snaps into place.
10. Then select the **Hot Key** button and press **Paper Feed**. The scanner should print a label that reads "**Paper Feed**".